

# DIY Mobile Home Windows



## MEASUREMENT INSTRUCTIONS

### YOU WILL NEED THE FOLLOWING

1 X HELPER

1 X TAPE MEASURE

1 X FLAT BLADE SCREWDRIVER

FROM INSIDE THE HOME TAKE A WIDTH & HEIGHT MEASUREMENT OF THE WINDOW APERTURE FROM WOOD TO WOOD, YOU WILL HAVE TO EITHER REMOVE THE PLASTIC CORNER MOULDINGS OR THE PLASTIC TRIM TO ALLOW YOU TO VIEW THE TIMBER, THIS MEASUREMENT SHOULD BE A TIGHT MEASUREMENT. ALWAYS MARK DOWN THE LOCATION OF THE WINDOW E.G – KITCHEN OR BEDROOM 1 OR FRONT MIDDLE ETC ETC.

DECIDE WHAT OPENING STYLE YOU REQUIRE FOR EACH WINDOW, CHOOSE FROM OUR STYLES ON OUR WINDOW STYLE PAGE. STANDARD ONES ARE FIXED OR FULL OPENING, IF YOU REQUIRE A FULL OPENING BUT THE WINDOW IS LARGER THAN 800MM SQUARE THEN YOU WILL NEED TO CHOOSE A SPLIT (HORIZONTALLY) WINDOW WITH AN OPENING TO THE LEFT OR RIGHT (VIEWED FROM OUTSIDE). WE ALSO MANUFACTURE TOP OPENING WINDOWS (AGAIN 800MM SQUARE IS THE LARGEST).

ONCE YOU ARE CONFIDENT YOU HAVE THE CORRECT MEASUREMENTS AND STYLES REQUIRED SEND US AN EMAIL FOR A QUOTATION.

### ON REQUEST PLEASE ADVISE THE FOLLOWING

SIZES OF APERTURE

STYLES OF WINDOWS

LOCATION OF WINDOWS ON HOME

DELIVERY ADDRESS

MAKE & MODEL OF HOME